

Assembly instructions for the 9 in1 System

Skin for Life

1-866-312-7546 (SKIN)

<http://www.skinforlife.com>

Step 1:



Open Box, Identify base of 9 in 1.

Step 2:



Remove top half of Styrofoam. Set it next to the box.
Remove base from Styrofoam.

Step 3:



Turn base so drilled holes are towards the right.

Step 4:



Place the base on the bottom of the 9 in 1 and attach with large Phillips screws supplied from the parts bag. Screw driver supplied in box with 9 in 1.

Step 5:



Make sure the screws are tight, and stand the machine attached to the base on its wheels.

Step 6



Find white (heavy) brackets for the steamer and maglight.
They should be in the box wrapped in bubble wrap.

Step 7:



Using the "Allen" wrench provided, install the flat white bracket to the back of the 9 in 1. Place the raised round portion of the tube end in the upright position. Use long Allen screws.

Step 8:



Using the same Allen wrench, install the bent steamer bracket to the side of the 9 in 1. Remember to place the bend forward. Use long Allen screws.

Step 9:



Unwrap steamer, remove bubble wrap from glass jar and reposition the jar carefully to assure a seal. Place steamer post into bracket hole.

Step 10:



Plug steamer into plug to the rightmost socket on the back of the machine.

Step 11:



Unwrap maglight and place in bracket on the right.

Step 12:



Plug maglight into the leftmost socket.

Step 13:



Install accessory tray. Use the four (4) holes located on the maglight side of the sterilizer. Use short Allen screws.

Step 14:



Final assembly of accessories tray.

Step 15:



Unwrap and install wire trays in sterilizer cabinet.

Step 16:



Using Allen wrench, install woods lamp bracket to back of 9 in 1 just above the base. Use short Allen screws.

Step 17:



Plug woods lamp into the center socket. Place lamp in holder.

Any further questions?
866-312-7546
